






Make sure that your grinder is unplugged when you proceed to the SpeediEdge assembly.



Feel the two plastic rings on both spherical bearings.



Use the short screw to assemble the two parts of the SpeediEdge.




The last step is to calibrate the SpeediEdge assembly - Place on flat surface


- Press the head of your grinder with one hand
- Release the break
- Position the block against the back of your grinder

Screw the spherical bearings on each side of the grinder using a wrench.

 \bigcirc



Clip the SpeediEdge on each side of the grinder.



Screw the handle with shock absorger on top.